



ARUBA – Setup at Liquor Agency

SETTING UP THE ARUBA RAP

Remote Access Point (RAP) – the remote access point or RAP is basically a Wi-Fi modem that allows the hand scanner to make a connection to the internet.



- 1) **Open box**, which contains the RAP, power supply and short network cable.
- 2) **Unpack the RAP** and assemble the stand, so it mounts upright on a flat surface.
- 3) **Connect the Ethernet cable** from the store internet source **to the connector** on the back of RAP marked **with the number 0**.
(When connecting directly to a cable modem, use the included short network cable to connect from the cable modem to the RAP connector with the number 0.)
- 4) **Connect the power** supply to the RAP.
- 5) Yellow and green lights show initial activity as it automatically configures itself.
- 6) This **setup portion will take 5 minutes or longer**, depending on the speed of the internet service at the store.
- 7) Activity will be shown in the form of flashing yellow and green lights.
- 8) Once the RAP is fully set up, you will see less light activity.
- 9) Power up the hand scanner to test for a successful connection.

Power Indicator



- 10) **IF THE GREEN POWER LIGHT IS FLASHING** and no other lights are blinking, you do not have a good internet connection. Check the cable connection.